

C₃F₈ fill procedure

C₃F₈ fill procedure

This procedure covers filling of the bubble chamber inner vessel with its nominal charge of C₃F₈. Obviously there is plenty of hazards and risk here, hence this is a written procedure.

- 1) Review procedure 4 "[C3F8 Handling Procedure](#)". **THIS HAS NOT BEEN WRITTEN**
- 2) Ensure that the hydraulic system is filled and appropriately initialized. It should be under neutral pressure, with the inner vessel at a slightly expanded bellows position. The bubble chamber should be completely filled with water, all the way up to the fill and bleed valves. All valves should be closed.
- 3) Start the "Commissioning Tool" VI and initiate data logging every 5 seconds.
- 4) Initiate cool-down¹ to just above 0°C. This will take a while. Follow procedure 6.2 [Bubble Chamber Temperature Ramp up/down](#) until an appropriate temperature has been achieved and stabilized. If the NESLAB bath contains only water, set it to maintain a bath temperature no lower than 2°C.
- 5) Assemble the C₃F₈ transfer lines, vacuum pump, transfer cart, C₃F₈ transfer bottle, and C₃F₈ sample bottle. The plumbing consists of a flexible connection from the C₃F₈ transfer bottle to the sample bottle. The line is equipped with a tee to a vacuum gauge, an isolation valve, and a vacuum pump. The pump down port should be near the sample bottle. The cart is equipped with an electronic balance. The C₃F₈ transfer bottle sits on the balance. Position the transfer line so that any condensed C₃F₈ flows into the sample bottle. Zero the balance. Place the sample bottle in an ice-water bath.
- 6) Ensure MV-011 and the transfer bottle valve are closed. Open the plumbing to the vacuum pump and evacuate the C₃F₈ transfer line. Once it is evacuated, open the valve to the empty sample bottle and evacuate it. The isolate and turn off the vacuum pump. Record the vacuum pressure, wait 5 minutes, and re-check the vacuum pressure to ensure there are no leaks.
- 7) Record the mass of the transfer bottle and of the sample bottle.
- 8) Follow the "Before Handling C₃F₈" section of procedure 4. **NOT WRITTEN**

¹ The actual temperature is not critical. It needs to be cool enough to maintain the distillation relative to the ~20°C reservoir temperature.

C_3F_8 fill procedure

- 9) Open the transfer bottle and condense some C_3F_8 into the sample bottle for 5 minutes, or until 50g has been transferred.
- 10) Close the valves to both bottles and rerecord the mass of the transfer bottle.
- 11) While facing away from the gas stream, vent the transfer line through the pump down port.
- 12) Disconnect the sample bottle and connect the transfer line to the bubble chamber main fill valve (MV-011).
- 13) Ensure MV-011 and the transfer bottle valve are closed. Open the plumbing to the vacuum pump and evacuate the C_3F_8 transfer line. Once that is evacuated, isolate and turn off the vacuum pump. Record the vacuum pressure, wait 5 minutes, and re-check the vacuum pressure to ensure there are no leaks.
- 14) Open MV-011 and ensure that the vacuum does not rise significantly above the vapour pressure of water. If it does, it indicates that gas has entered the inner vessel. Close MV-011.
- 15) Compress (slightly) the chamber. Be very careful not to generate a pressure more than a few psi. It is only necessary to take the slack out of the system so that the bellows do not overextend when the inner vessel is pressurized with C_3F_8 gas.
- 16) Verify that the vacuum pump is isolated and MV-011 is closed, then slowly open the valve to the C_3F_8 tank to pressurize the lines. The line pressure should rise to approximately 115psi.
- 17) Begin the distillation by opening MV-011. Open MV-012 slightly, such that water leaks slowly from the bleed line, but does not allow C_3F_8 to boil out. The goal is to keep chamber pressure high enough to prevent C_3F_8 from boiling, so that it condenses in the fill line and settles to the bottom of the chamber while only water is displaced through MV-012. This will require delicate modulation of MV-012. There should be a large pressure differential across MV-012.
- 18) Once a valve position has been established that allows continuous and steady distillation of C_3F_8 , allow distillation to proceed until the desired mass of C_3F_8 has been transferred from the vessel into the chamber. Over time, C_3F_8 should be observed forming a puddle in the bottom of the vessel. The mass in the C_3F_8 tank should continually decrease. This may take a long time.

C_3F_8 fill procedure

- 19) Cross-check the mass transfer data, the C_3F_8 level in the vessel, and the quantity of water removed from the vessel. Make sure the appropriate amount of fluid has been transferred.
- 20) Isolate the C_3F_8 transfer bottle.
- 21) Wait for the overpressure of C_3F_8 in the transfer line to condense. When the pressure is minimized, close MV-011 and isolate the transfer line.
- 22) Vent the transfer line and disconnect it from both the inner vessel and the transfer bottle. Cap the transfer bottle and the inner vessel port.
- 23) Ensure the "After Handling C_3F_8 " section of procedure 3 was followed.
- 24) Slowly charge the hydraulic system. Once you've established that the inner vessel is "floating" (i.e. that when all of the C_3F_8 is condensed the bellows is off its stop) the pressure can be run up to the nominal 200 psig.
- 25) Initiate warm up of the chamber to its operating point following procedure 2.5 "Bubble Chamber Temperature Ramp up/down".
- 26) Terminate data acquisition and backup the data by rsync'ing with the coupp2ls1 data disk.